



TITAN[®]
CONTROLS

APOLLO 6[®]

24 Hour Analog Timer
with 15 minute intervals

Instructions for Operation

1. To set present time: Turn the programming dial in the direction of the arrow until the triangular mark corresponds with the present time.
 2. To program: Ensure the arrow is on the present time. Push in the trippers situated around the dial to set equipment "ON" time. Each tripper represents 15 minutes.
 3. For example: If you would like to set the time of activation from 11:00 AM to 1:30 PM, then push down the trippers situated between 11:00 AM and 1:30 PM, including the segments corresponding with 11:00 AM and 1:30 PM.
 4. To activate equipment: Having selected your program, plug in your equipment to the timer and then plug the timer into a 120 Volt circuit. The timer will activate and de-activate the equipment as the dial rotates through the pushed down segments.
 5. The selected program will remain the same each day unless modified by customer.
- 120 Volts/ 15 Amps/60 Hz/1800 Watts
 - For Indoor Use Only
 - 1 year warranty

WARNING: DO NOT OVERLOAD