

Connect wires from wire cable to LuxPro (LUXPRO PSP511Ca) Thermostat ports where indicated.

IMPORTANT:

Connect Port O to Port B with a jumper wire (not included).

Connect Port RH to Port RC with a jumper wire (not included).

